Macro	Purpose
dl_buf_init	Initialize the buffer API
dl_buf_alloc	Allocate a packet buffer
dl_buf_free	Deallocate a packet buffer
dl_buf_get_desc	Return SRAM pointer to metadata from a buffer
dl_buf_get_data	Return DRAM pointer to buffer data area
dl_meta_init_cache	Populate a metadata cache
dl_meta_flush_cache	Flush metadata cache to SRAM
dl_meta_get_buffer_next	Move to next buffer in a chain
dl_meta_get_offset	Find offset of data within a buffer
dl_meta_get_free_list	Find free list from which buffer was allocated
dl_meta_get_rx_stat	Extract receive status from a buffer
dl_meta_get_buffer_size	Find the size of data in a given buffer
dl_meta_get_packet_size	Find the total size of a packet
dl_meta_get_input_port	Find the input port over which packet arrived
dl_meta_set_output_port	Set the output port to which packet will be sent