Constant	Value And Meaning
SA_CONSUME_NUM	The number of packets an ingress microACE processes for each StrongARM packet. A value of N means that N-1 MAC packets will be processed each time one StrongARM packet is processed. The usual value is thirty-one.
IX_EXCEPTION	The value for macros to return when raising an exception. The usual value is zero.
SEQNUM_IGNORE	A sequence number to assign to StrongARM packets when using Gigabit Ethernet (FastPort)

Figure 25.5 The symbolic constants that must be defined before Intel's dispatch loop macros can be included in a program.