Field	Type	Purpose
name	**string**	**Name of the ACE in ixsys.config**
tag	**int**	**ID of ACE assigned by Resource Manager**
ue	**int**	**Bitmask of microengines running the ACE**
bname	**string**	**TAG name that the microblock uses**
ccbase	**ix_base_t**	**Handle for crosscall service**

Figure 26.3 Additional fields in the control block for the wwbump ACE. The control block begins with the *ix_ace* structure that the Intel software requires.