Operation	Meaning
incr	Increment the specified word in memory
decr	Decrement the specified work in memory
add	Add the value in a transfer register to the specified word in memory
sub	Subtract the value in a transfer register to the specified word in memory